



Installation Instructions for Model A-SM1 FallGuard® Skylight Screens

Skylight can be brittle. Do Not Touch Dome, Pyramid, or Glazing. Wear Gloves when handling screen. Wear Safety Glasses when installing FallGuard® Rails.

- 1. Center FallGuard® Rail onto Length Side of Skylight Retaining Frame**
- 2. Secure the FallGuard® Rail on to skylight retaining frame with specially provided galvanized steel hex washer self-drilling screws through the pre-punched holes.**
- 3. Center the screen over the skylight and Install the Bases of the Screens into the Rail Notch openings.**
- 4. Install the furnished stainless Steel Clips by snapping them in place on the rail notches. Start on the ends and space about ~12-18” apart (One Bag Per FallGuard®. Clips don’t need to be on all Notches).**

Model A-SM1 FALLGUARD® Skylight Screen

Patent No.
5,237,788

